USED PRODUCT RECYCLE INCENTIVE PROGRAM

For our better environment we at Kingpin Trading Limited encourage our end users to recycle used Turbo Brand products. For this cause we provide the following trade-in incentive for our end users' convenience.





1) Mechanics

The end user is encouraged to bring their used Turbo product in its complete form (including accessories, defective units are accepted) to our Customer Service Centre (please refer to the warranty card of this instruction manual for its address) for trading in a brand new Turbo Brand product of any categories on a one-for-one basis at 20% discount of the selected new product's normal retail price. The used product will be collected by professional recycling organizations.

2) Terms & Conditions:

- 2.1) Normal product warranty is offered to the selected new product. However, selected product is not returnable.
- 2.2) The selected new product can be different from the used product in product category and model regardless of the respective retail price, e.g. a used humidifier can be traded in for a dehumidifier.
- 2.3) The used Turbo product must come from Kingpin Trading Limited's past or current product lines. Products distributed by other companies will not be accepted.
- 2.4) For proper handling, used product in dismantled form will not be accepted.
- 2.5) The trade-in transaction will be completed at our Customer Service Centre. No transportation service whatsoever will be provided.
- 2.6) The selected new product will be paid for in cash. Official receipt will be provided.
- 2.7) The used product will neither be refunded nor exchanged for cash.
- 2.8) In case the original retail price of the used product is higher than the discounted price of the selected new product, the difference will not be compensated in cash or other product.
- 2.9) The trade-in price is not guaranteed to be the most favorable in the market.
- 2.10) Selected new product is only available while stocks last.
- 2.11) Kingpin Trading Limited has the final decisions concerning all matters of this program.
- 2.12) Kingpin Trading Limited reserves the right to terminate this program without further notice at any time, and to amend the terms and conditions of this program at its discretion.

เงื่อนไขการรับประกันสินค้าประเภทพัดลมของบริษัทฯ

- 1 บุริษัทุฯจะรับประกันมอเตอร์า ปี และอะไหลที่เกี่ยวข้องกับระบบไฟฟ้าเป็นระยะเวลา 1 ปี ภายใต้เงื่อนไขสินค้า ต้องใช้งานถูกต้องตามปกติของการใช้งานหรือการชำรุคบกพร่อง เนื่องจากการผลิต
- | 2 บริษัทฯฟรีคาบริการปีแรก สำหรับปีต่อไปคิดคาบริการตามอัตราที่บริษัทฯกำหนด
- 3 ความรับผิดขอบของบริษัทฯ ต่อการประกันสินค้าจะสิ้นสุดลงในกรณีดังต่อไปนี้
 - 2.1 บัตรประกันสูญหายหรือมีรอยแก้ไข ขูด ลบ โดยไม่ได้รับอุนุมัติจากบริษัทฯ
 - 2.2 ความเสียหายอันเกิดจากการเคลื่อนย้าย ขนส่ง ทำตกหลุ่น
 - 2.3 ความเสียหายอันเกิดจากการใช้ผิดวิธี ความประมาทหรือเจตนาทำให้เสียหาย
 - 2.4 ความเสียหายอันเกิดจากอุบัติเหตุ ภัยธรรมชาติ ความผิดปกติของกระแสไฟฟ้า แรงดันหรือความ เป็นกรดเป็นดางของ น้ำที่ผ่านเข้าเครื่อง
 - 2.5 ความเสียหายอันเกิดจากสัตว์เข้าไปกัด แทะ หรืออาศัย

 - 2.6 ความเสียหายอันเกิดจากการติดตั้ง ดัดแปลง ตอเติม แก้ไข ซอมแซมโดยชางอื่นๆ ซึ่งมิใชชางของบริษัทฯ
 2.7 บริษัทฯ จะไม่รับประกันสินค้าที่ใช้แล้ว ซึ่งผู้ชื่อทำการซื้อตอจากบุคคลอื่น โดยมิโดซื้อจากบริษัทฯ หรือตัวแทน
 - 2.8 บริษัทฯ ไม่รับประกันส่วนประกอบภายนอก ที่เกิดการแตก หัก ชำรุด เช่น ชิ้นส่วนพลาสติก ใบพัดแตกหัก ทคหมคกฉีกขาดฯลฯ
- | 4 สำหรับลูกค้าซึ่งมีภูมิลำเนาอยู่นอกเขต กทม. และปริมณฑล(ปทุมธานี/นนทบุรี/สมุทรปราการ) และสำหรับลูกค้า ที่ต้องการ ตรวจขอมสินค้าทุกประเภท หากต้องการให้บริษัทฯสงชางไปตรวจขอมสินค้าให้ไมวาจะอยู่ในช่วงระยะเวลา รับประกันหรือไม ก็ตามลูกค้าต้องรับผิดชอบค่าใช้จายในการเดินทางของชางด้วยตนเอง โดยสามารถเช็คได้ที่ศูนย์บริการทุกสาขา
- (5 บริษัทข้ออสงวนสิทธิ์ไม่รับประกันสินค้าที่ลูกค้านำไปใช้ในกิจการเชิงพาณิชย์

บริษัท แอสที่นา (ประเทศไทย) จำกัด 36/19-20 ซ.รามคำแหง 43/1 ถ.รามคำแหง แขวงพลับพลา เขตวังทองหลาง กรงเทพฯ 10310 www.astinathailand.com

ศูนยบริการซอม-อะไหล โทร. 02-934-7080,02-934-4529 แฟ็กซ์ 02-934-5448





คู่มือการใช้พัดลม

Model: AC 011C





โปรดอานคู่มือการใช้ให้ละเอียดก่อนการใช้งาน

IMPORTANT SAFETY INSTRUCTIONS

- 1. Read all instruction carefully and keep this manual for future reference.
- 2. Do not let the appliance touch any hot surfaces.
- 3. To avoid electric shock, do not place the cord, the plug or the appliance in water or other liquids.
- 4. Close supervision is necessary when the appliance is used by or near the children.
- 5. Unplug the plug outlet when not in use and before cleaning.
- 6. Do not operate the appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return the appliance to our customer service centre for examination.
- 7. Do not let the cord hang over the edge of a table or counter or touch hot surfaces.

Do not place the appliance on an unsteady or cloth covered surface.

- 8. Please check the power cord & the plug firstly to see if they are normal, and check the body to see if there is any a crack or damages. If there is any abnormal, please call the customer service hotline for assistance.
- 9. When you are going to move the fan or not in use, please cut off the power and unplug the plug.
- 10. Do not use the fan in the area at high humility, temperature higher than 40% or dusty area.
- 11. Do not insert the fingers or other objects into the fan during operation. Especially take care of the children.
- 12. Please do not blow to the elder, the children or the patient directly for a long time.
- 13. Do not spray any detergent such as bug or mosquito killer into the fan to prevent it from damages to the plastic material.
- 14. The appliance is for household use only. Do not use at outdoors or for any commercial or industrial purpose.
- 15. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 16. Children should be supervised to ensure that do not play with the appliance.

- 17. Always disconnect the mains power, before any user maintenance.
- 18. If the supply cord is damaged, it must be replaced by the sole distributor, its service agent or similarly qualified persons in order to avoid a hazard.
- 19. Please ensure that the fan is switched off from the supply mains before removing the guard.
- 20. Only use on 220V./50Hz power supply.
- 21. Do not operate the fan in the presence of explosive and/or flammable fumes.
- 22. Do not place the fan or any parts near an open flame, cooking or other heating appliance.
- 23. Do not hang or mount fan on a wall or ceiling.
- 24. Do not operate if the fan housing is damaged.

FAN OPERATION

Plug into any AC 220-240V, 50Hz source, insure that the plug and the socket fit well. Then you can operate the appliance.

Your fan is equipped with a 3-position speed control switch..

Speed control switch:

SYMBOL	FUNCTION
0	OFF
1	low speed
2	high speed

CLEANING AND MAINTENANCE

Unplug the fan before cleaning.

Use only a piece of soft, damp cloth to gently wipe the outer surfaces of the fan clean.

To clean between the grilles, we recommend using a pipe cleaner, flexible dustwand, vacuum cleaner or compressed air to gently remove the dust. DO NOT immerse the fan in water and never allow water to drip into the motor housing.

DO NOT use gasoline, paint thinner or other chemicals to clean the fan. For storage, you may leave the fan assembled and covered to protect it from dust. Store the fan in a cool, dry place.



This product contains recyclable materials. Do not dispose this product as unsorted municipal waste. Please contact your local municipality for the nearest collection point.